



ZAPI[®] S.p.A.


**ELECTRONIC • OLEODYNAMIC • INDUSTRIAL
EQUIPMENTS CONSTRUCTION**

Via Parma, 59 – 42028 – POVIGLIO (RE) – ITALY
Tel +39 0522 960050 (r.a.) – Fax +39 0522 960259
e-mail: zapi@zapispa.it – web: www.zapispa.it

EN

User Manual

GRAPHIC SMART DISPLAY



The contents of this publication is a ZAPI S.p.A. property; all related authorizations are covered by Copyright. Any partial or total reproduction is prohibited.

Under no circumstances will Zapi S.p.A. be held responsible to third parties for damage caused by the improper use of the present publication and of the device/devices described in it.

Zapi spa reserves the right to make changes or improvements to its products at any time and without notice.

The present publication reflects the characteristics of the product described at the moment of distribution. The publication therefore does not reflect any changes in the characteristics of the product as a result of updating.



ZAPI® is a registered trademark property of Zapi S.p.A.

NOTES LEGEND



The symbol aboard is used inside this publication to indicate an annotation or a suggestion you should pay attention.



The symbol aboard is used inside this publication to indicate an action or a characteristic very important as for security. Pay special attention to the annotations pointed out with this symbol.

Contents

1	INTRODUCTION	5
2	GENERAL CHARACTERISTICS	6
2.1	Technical specifications	6
2.1.1	Dashboard	6
2.1.2	Alphanumeric LCD (Liquid Crystal Display).....	6
2.2	Functional descriptions	7
2.2.1	LED function	7
2.2.2	Display function.....	8
3	INSTALLATION HINTS	10
3.1	Material overview	10
3.1.1	Connection cables	10
3.1.2	Fuses	10
3.2	Installation of the hardware.....	10
3.2.1	Dashboard heating.....	11
3.2.2	Wirings: CAN connections and possible interferences	11
3.2.3	Wirings: I/O connections	13
3.2.4	Insulation of truck frame.....	14
3.3	Protection and safety features	14
3.3.1	Protection features.....	14
3.3.2	Safety Features.....	14
3.4	EMC.....	15
4	DIAGNOSIS.....	17
5	DESCRIPTION OF CONNECTORS	18
5.1	CNA connector: Molex Minifit 6 pins	18
5.2	CNB connector: Molex Minifit 4 pins	18
5.3	CNC connector: Molex Minifit 12 pins.....	18
6	DRAWINGS	20
6.1	Mechanical drawing	20
6.2	Connection drawing	21
7	PROGRAMMING AND ADJUSTMENTS USING ZAPI HANDSET	22
7.1	Adjustment via console	22
7.2	Description of standard console menu	23
7.3	Description of programmable functions	24
7.4	Special Adjustment menu	26
7.5	Hardware Setting	26
7.6	Tester menu.....	27
7.7	Description of console using	29
7.8	Other functions	31
7.9	Description of Alarm menu	32
8	STRUCTURE OF DISPLAY MENU.....	33
8.1	Performance rolling.....	35
8.2	Using of Password menu.....	35
8.3	Using dashboard like a console	36
8.4	Set Date/Hour menu	36
9	ANALYSIS OF GRAPHIC SMART DISPLAY RELATED ALARMS	37
9.1	Graphic Smart Display alarms	37
9.2	Graphic Smart Display warnings	38

9.3	Alarms visualisation.....	38
10	RECOMMENDED SPARE PARTS	42
11	PERIODIC MAINTENANCE TO BE REPEATED AT TIMES INDICATED.....	43

APPROVAL SIGNS

COMPANY FUNCTION	INIZIALS	SIGN
PROJECT MANAGER	FG	
TECHNICAL ELECTRONIC MANAGER VISA	PP	
SALES MANAGER VISA	MC	

Publication N°: **AF4ZP0AB**
Edition: **May 2009**

1 INTRODUCTION

Graphic Smart Display is an intelligent dashboard connected to the truck system by CAN-BUS line.

This dashboard provides the diagnostic and set-up of the whole truck system: Graphic Smart Display itself, Traction controller, Pump controller, Valves controller.

It has an alphanumeric liquid crystal display (LCD) and a built-in backlight.

Access to Graphic Smart Display menu structure is provided by six operator buttons integrated in a membrane keyboard.

Furthermore this dashboard has six built-in red LED, which provide the operator with a easy information about the status of some truck devices.

2 GENERAL CHARACTERISTICS

2.1 Technical specifications

2.1.1 Dashboard


Voltage:.....	24/36/48/80 V
Can interface [n°]:	1
Keyboard buttons [n°]:	6
LED [n°]:	6
Protection:.....	IP65 (Front); IP55 (Bottom)
External temperature range: standard version	-10÷50 °C
External temperature range: frozen cell version	-30÷50 °C

2.1.2 Alphanumeric LCD (Liquid Crystal Display)

Viewing area (WxH).....	67.0x46.0 mm
Number of pixels [n°]	240x160
Pixel size.....	0.28x0.28 mm
Yellow-green backlight: number of LED	12

2.2 Functional descriptions

2.2.1 LED function



The Graphic Smart Display has six built-in red LED, which provide the operator with an easy information about the status of some truck devices.

Battery(1)

This led lights when the measured battery voltage is equal or less than 40% nominal battery voltage.

Wrench (2)

This led blinks when truck is in alarm condition.

Thermometer (3)

This led blinks when one truck's controller is in alarm due IMS high temperature.

Seat (4)

This led lights when the operator is not on the seat.

Handbrake (5)

This led lights when the handbrake is activated.


Seat belt (6)

This led lights to signal that the seat belt is not correctly fastened. The Seat belt sensor must be connected to the Analogue Input #2 (CNC#8).



When the Key Switch is closed, the Graphic Smart Display makes a general test lighting and switching off all the LED in sequence.

2.2.2 Display function



Battery's state of charge

The battery's state of charge indication ([number 1](#) in figure) is displayed on the left side of the unit; it is shown by ten notches. Each notch represents the 10% of the battery charge. As the battery becomes discharged, the notches turn off progressively, one after the other, in proportion to the value of the residual battery charge. When the residual battery charge is $\leq 40\%$ the notches displayed start to blink. When Battery Low alarm appears on the traction controller, the battery symbol which is near the notches also blinks.

Performance

The letter which appears in the rectangle displayed in the top right side of the unit ([number 2](#) in figure) shows the performance mode which is being used in the controller.

Performances can be scrolled pressing button ESC. When one performance is selected, the related information will be sent via can-bus to traction and pump controllers that will manage this data. The standard functioning reduces truck performance passing from the high to economic performance.

The real meaning, in terms of parameters level of these performances, depends on software present on pump and traction controllers:

- "H" corresponds to highest performance;
- "N" corresponds to normal performance;
- "E" corresponds to low-economic performance;

Turtle

The turtle symbol ([number 3](#) in figure) is normally off; when it appears (fixed) it shows activation of the "soft" mode of the truck, in which maximum speed and

acceleration are reduced. The “soft” mode can be activated pressing button  (↓).

Hour meter

The number displayed on the bottom right side of the unit ([number 4](#) in figure) shows the Hours Worked.

The letter present near the hour meter([number 5](#) in figure) shows which hour meter is displayed:

- K: the key hour meter is displayed;
- T: the traction hour meter is displayed;
- P: the pump hour meter is displayed; it increases if pump control is working.

Accelerator

The accelerator level indication ([number 6](#) in figure) is displayed on the central top side of the unit; it is shown by ten notches. When the accelerator level is minimum only a notch is displayed, when the accelerator level is maximum all the ten notches are displayed. Each notch represents 1/10 of the difference between maximum and minimum accelerator level.

Speed

The number displayed under the accelerator notches on the center of the unit ([number 7](#) in figure) shows the truck speed. The unit can be km/h or mph depending on the SPEED UNIT parameter setting (see 7.4).

Wheel position and running direction

The notch displayed on the left of the hour meter ([number 8](#) in figure) represents the wheel (only one of the nine notches is displayed) and shows the steering angle (it corresponds to the relative truck direction if the truck is running).

The arrow ([number 9](#) in figure) shows the set truck running direction. The arrow point is up when the truck is forward running; the arrow point is down when the truck is reverse running. If the truck doesn't run a dot is displayed instead of the arrow.

3 INSTALLATION HINTS

In the description of these installation suggestions you will find some boxes of different colours, they mean:



These are **information** useful for anyone is working on the installation, or a deeper examination of the content



These are **Warning boxes**, they describe:

- operations that can lead to a failure of the electronic device or can be dangerous or harmful for the operator;
- items which are important to guarantee system performance and safety

3.1 Material overview

Before starting it is necessary to have the required material for a correct installation. Otherwise a wrong choice of cables or other parts could lead to failures/ misbehaviour/ bad performances.

3.1.1 Connection cables

For the auxiliary connections, use cables of 0.5-1.0 mm² section.

3.1.2 Fuses

- Use a 10A Fuse for protection of the card.
- For Safety reasons, we recommend the use of protected fuses in order to prevent the spread of fused particles in case the fuse blow.

3.2 Installation of the hardware



Before doing any operation, ensure that the battery is disconnected and when all the installation is completed start the machine with the drive wheels raised from the floor to ensure that any installation error do not compromise safety.

Do not connect the module to a battery with a nominal voltage different than the value indicated on the label. A higher battery voltage may cause a logic failure. A lower voltage may prevent the logic from operating.

3.2.1 Dashboard heating


Graphic Smart Display does not need any means of heat dissipation. The frozen-cell version, provided with a built-in heater, is strongly recommended for frozen-cell applications.

3.2.2 Wirings: CAN connections and possible interferences



CAN stands for Controller Area Network. It is a communication protocol for real time control applications. CAN operates at data rate of up to 1 Megabits per second.


It was invented by the German company Bosch to be used in the car industry to permit communication among the various electronic modules of a vehicle, connected as illustrated in this image:



- The best cable for can connections is the twisted pair; if it is necessary to increase the immunity of the system to disturbances, a good choice would be to use a cable with a shield connected to the frame of the truck. Sometimes it is sufficient a simple double wire cable or a duplex cable not shielded.
- In a system like an industrial truck, where power cables carry hundreds of Ampere, there are voltage drops due to the impedance of the cables, and that could cause errors on the data transmitted through the can wires. In the following figures there is an overview of wrong and right layouts of the cables routing.



Wrong Layout:




The red lines are can wires.
The black boxes are different modules, for example traction controller, pump controller and display connected by canbus.
The black lines are the power cables.

This is apparently a good layout, but can bring to errors in the can line.
The best solution depends on the type of nodes (modules) connected in the network.
If the modules are very different in terms of power, then the preferable connection is the daisy chain.



Correct Layout:




Note: Module 1 power > Module 2 power > Module 3 power

The chain starts from the –BATT post of the controller that works with the highest current, and the others are connected in a decreasing order of power.
Otherwise, if two controllers are similar in power (for example a traction and a pump motor controller) and a third module works with less current, the best way to deal this configuration is to create a common ground point (star configuration).



Correct Layout:



Note: Module 1 power \approx Module 2 power $>$ Module 3 power

In this case the power cables starting from the two similar controllers must be as short as possible. Of course also the diameter of the cable concurs in the voltage drops described before (higher diameter means lower impedance), so in this last example the cable between the minus of the Battery and the common ground point (pointed by the arrow in the image) must be dimensioned taking into account thermal and voltage drop problems.



Can advantages

The complexity of today systems needs more and more data, signal and information must flow from a node to another. CAN is the solution to different problems that arise from this complexity

- simplified design (readily available, multi sourced components and tools)
- lower costs (less and smaller cables)
- improved reliability (fewer connections)
- analysis of problems improved (easy connection with a pc to read the data flowing through the cable).

3.2.3 Wirings: I/O connections

- After crimping the cable, verify that all strands are entrapped in the wire barrel.
- Verify that all the crimped contacts are completely inserted on the connector cavities.



A cable connected to the wrong pin can lead to short circuits and failure; so, before turning on the truck for the first time, verify with a multimeter the continuity between the starting point and the end of a signal wire.

- For information about the mating connector pin assignment see the paragraph "description of the connectors".

3.2.4 Insulation of truck frame



As stated by EN-1175 “Safety of machinery – Industrial truck”, chapter 5.7, “there shall be no electrical connection to the truck frame”. So the truck frame has to be isolated from any electrical potential of the truck power line.

3.3 Protection and safety features

3.3.1 Protection features

- **Connection Errors:**
All inputs are protected against connection errors.
- **External agents:**
The dashboard is protected against dust and the spray of liquid to a degree of protection meeting IP55.

3.3.2 Safety Features



ZAPI devices are designed according to the prEN954-1 specifications for safety related parts of control system and to UNI EN1175-1 norm.

The safety of the machine is strongly related to installation; length, layout and screening of electrical connections have to be carefully designed. ZAPI is always available to cooperate with the customer in order to evaluate installation and connection solutions. Furthermore, ZAPI is available to develop new SW or HW solutions to improve the safety of the machine, according to customer requirements.

Machine manufacturer holds the responsibility for the truck safety features and related approval.



EMC and ESD performances of an electronic system are strongly influenced by the installation. Special attention must be given to the lengths and the paths of the electric connections and the shields. This situation is beyond ZAPI's control. Zapi can offer assistance and suggestions, based on its years experience, on EMC related items. However, ZAPI declines any responsibility for non-compliance, malfunctions and failures, if correct testing is not made. The machine manufacturer holds the responsibility to carry out machine validation, based on existing norms (EN12895 for industrial truck; EN50081-2 for other applications).

EMC stands for Electromagnetic Compatibility, and it represents the studies and the tests on the electromagnetic energy generated or received by an electrical device.

So the analysis works in two directions:

- 1) The study of the **emission** problems, the disturbances generated by the device and the possible countermeasure to prevent the propagation of that energy; we talk about “conduction” issues when guiding structures such as wires and cables are involved, “radiated emissions” issues when it is studied the propagation of electromagnetic energy through the open space. In our case the origin of the disturbances can be found inside the controller with the switching of the mosfets which are working at high frequency and generate RF energy, **but wires and cables have the key role to propagate the disturbs because they works as antennas**, so a good layout of the cables and their shielding can solve the majority of the emission problems.
- 2) The study of the **immunity** can be divided in two main branches: protection from electromagnetic fields and from electrostatic discharge.
The **electromagnetic immunity** concern the susceptibility of the controller with regard to electromagnetic fields and their influence on the correct work made by the electronic device.
There are well defined tests which the machine has to be exposed to. These tests are carried out at determined levels of electromagnetic fields, to simulate external undesired disturbances and verify the electronic devices response.
- 3) The second type of immunity, **ESD**, concerns the prevention of the effects of electric current due to excessive electric charge stored in an object. In fact, when a charge is created on a material and it remains there, it becomes an “electrostatic charge”; ESD happens when there is a rapid transfer from a charged object to another. This rapid transfer has, in turn, two important effects:
this rapid charge transfer can determine, by induction, disturbs on the signal wiring and thus create malfunctions; **this effect is particularly critical in modern machines, with serial communications (canbus) which are spread everywhere on the truck and which carry critical information.**
in the worst case and when the amount of charge is very high, the

discharge process can determine failures in the electronic devices; the type of failure can vary from an intermittently malfunction to a completely failure of the electronic device.



IMPORTANT NOTE: it is always much easier and cheaper to avoid ESD from being generated, than to increase the level of immunity of the electronic devices.

There are different solutions for EMC issues, depending on level of emissions/ immunity required, the type of controller, materials and position of the wires and electronic components.

4) EMISSIONS. Three ways can be followed to reduce the emissions:

SOURCE OF EMISSIONS: finding the main source of disturb and work on it.

SHIELDING: enclosing contactor and controller in a shielded box; using shielded cables;

LAYOUT: a good layout of the cables can minimize the antenna effect; cables running nearby the truck frame or in iron channels connected to truck frames is generally a suggested not expensive solution to reduce the emission level.

5) ELECTROMAGNETIC IMMUNITY. The considerations made for emissions are valid also for immunity. Additionally, further protection can be achieved with ferrite beads and bypass capacitors.

6) ELECTROSTATIC IMMUNITY. Three ways can be followed to prevent damages from ESD:

PREVENTION: when handling ESD-sensitive electronic parts, ensure the operator is grounded; test grounding devices on a daily basis for correct functioning; this precaution is particularly important during controller handling in the storing and installation phase.

ISOLATION: use anti-static containers when transferring ESD-sensitive material.

GROUNDING: when a complete isolation cannot be achieved, a good grounding can divert the discharge current through a "safe" path; the frame of a truck can works like a "local earth ground", absorbing excess charge. **So it is strongly suggested to connect to truck frame all the parts of the truck which can be touched by the operator, who is most of the time the source of ESD.**

4 DIAGNOSIS

Graphic Smart Display microcontroller continuously monitors the output stages and carries out a diagnostic procedure on the main functions.

Main fault diagnostic function concern: parameter and password memory, canbus interface, output drivers.

5 DESCRIPTION OF CONNECTORS

5.1 CNA connector: Molex Minifit 6 pins

A1	-BATT	Power supply negative reference
A2	-BATT	Power supply negative reference
A3	CAN H	Can signal high
A4	CAN L	Can signal low
A5	HEATER+	Heater positive power supply. This input must be connected to +BATT before the key switch.
A6	KEY	Key input

5.2 CNB connector: Molex Minifit 4 pins

B1	NAUX	Auxiliary load output. The external load is driven to – Batt.
B2	PAUX	Auxiliary load positive supply. This output is internally connected to the key through a diode (cathode connected to CNB#2)
B3	CANT	Internally connected to CNA#4 through a Can-Bus 120 Ohm termination resistance. Connecting CNB#3 to CNA#3 the termination resistance is inserted between CAN L and CAN H.
B4	+BATT	Power supply positive reference. This input must be connected to +BATT before the key switch. CNB#4 supplies Graphic Smart Display also after the Key is switched OFF for a programmable service time.


5.3 CNC connector: Molex Minifit 12 pins

C1	FLASH BOOT	This input is used for the software download through the microcontroller Asynchronous Serial Interface. To connect the input to CNC#6 during this operation otherwise leave it open.
C2	NCLRxD	Serial reception negative
C3	PCLTxD	Serial transmission positive
C4	NCLTxD	Serial transmission negative
C5	GND	Console negative power supply
C6	+12	Console positive power supply
C7	AN/DI 1	Analogue/digital input #1
C8	AN/DI 2	Analogue/digital input #2
C9	AN/DI 3	Analogue/digital input #3


C10	AN/DI 4	Analogue/digital input #4
C11	NPOT	Power supply negative reference. It is used as potentiometer negative.
C12	PAN-IN	Potentiometer positive: 12 V / 5 V output; keep load > 1kW / 0,5 KW

6 DRAWINGS

6.1 Mechanical drawing



6.2 Connection drawing




7 PROGRAMMING AND ADJUSTMENTS USING ZAPI HANDSET


7.1 Adjustment via console

Adjustment of Parameters and changes to the display configuration are made using the Digital Console.

Description of console and connection



7.2 Description of standard console menu



7.3 Description of programmable functions

MENU SET MODEL

1) **CONNECT TO**

Using CANBUS link, every module connected to can net can act as the “access node” to the canbus net for the external world.

For example the ZAPI hand console (or the PC-Win console) can be physically connected to one module and, by the canbus, virtually connected to any other module of the net.

This parameter is used to select the module to which the user wishes to be connected.

Following the numbers associated to each module in Zapi canbus system are showed.

Number associated in canbus net	MODULE
01	SICOS
02	TRACTION
03	TRACTION MASTER
04	TRACTION SLAVE
05	PUMP
06	EPS-AC
09	MHYRIO/HVC
16	GRAPHIC SMART DISPLAY

MENU SET OPTIONS

1) **PERFORM. ENABLE**

It can enable or disable operator changing the truck performances using button 5

- ON: Enabled operator
- OFF: Not enabled operator

2) **PERFORMANCE TYPE**

It sets the truck performances.

- LEVEL 0 : E (Economic performance)
- LEVEL 1 : N (Normal performance)
- LEVEL 2 : H (High performance)

3) **USER PWD**

It sets using of the starting password to main page access.

- ON: Starting password requeste
- OFF: Starting password not requested

4) **CONSOLE ENABLE**

It can active or disable using of console function

- ON: Console function active

- OFF: Console function disable

5) SPEED UNIT

It sets the speed unit:

OPTION #1: the speed unit is km/h

OPTION #2: the speed unit is mph

6) HOUR COUNTER

It sets the hour counter displayed.

OPTION #1: the traction hours are displayed

OPTION #2: the displayed hours represent the machine hour counter managed by the display

7) BRAKE ACT CLS

It sets active logic level of handbrake input (C7)

- ON: Active high input

- OFF: Active low input

8) SEATBELT ACT CLS

It sets active logic level of seat input (C8)

- ON: Active high input

- OFF: Active low input

9) AUX OUTPUT#1

The options are:

PRESENT: An external load is connected between PAUX and NAUX. The related diagnosis are enabled.

ABSENT: No external load is connected between PAUX and NAUX. The related diagnosis are disabled.

10) ODOMETER

It shows the distance traveled instead of hourmeter. It's possible to switch between totale distance and partial distance (trip meter) by pressing key 4. Keep pressed key 4 to reset trip meter.

MENU ADJUSTMENTS

1) DELAY DISPLAY OFF

This parameter sets the display ON "Service time". If the CNB#4 is connected to +Batt after Key-Off the display is still supplied for a programmable time, follow the table below to choose your temporization:

DELAY DISPLAY OFF LEVEL	0	1	2	3	4	5	6	7	8	9
SERVICE TIME [Sec]	1	3	5	7	9	11	13	15	17	20

2) SPEED FACTOR

It adjusts speed coefficient to have the correct truck speed value shown on the display. This coefficient has to be regulated depending on truck mechanic characteristics. It is the result of following formula:

$$\text{Speed Factor} = (88 * rr * p) / \emptyset$$

Where:

rr = total gearbox reduction ratio

p = number of pair pole of the motor

∅ = traction wheel diameter expressed in centimeters (cm)

3) AUX VOLTAGE#1

It specifies the percentage of battery voltage supplied to AUX coil to close the AUXILIARY electro valve. This parameter can be changed in the range 0% to 100%.

4) CHECK UP TYPE

It defines the truck behaviour when a maintenance is required.

LEVEL 0: the "SERVICE REQUIRED" alarm doesn't appear

LEVEL 1: the "SERVICE REQUIRED" alarm appears after a time equal to the hours set in the CHECK UP HOURS parameter

LEVEL 2: the "SERVICE REQUIRED" alarm appears after a time equal to the hours set in the CHECK UP HOURS parameter and after 50 additional hours the truck speed is reduced

5) CHECK UP HOURS

It defines the hours after which a maintenance is required. It can be adjusted in the 100 to 1000 hours. The resolution is 100 hours (it can be adjusted in steps of 100 hours).

6) CHECK UP DONE

It can be ON/OFF. This parameter is normally off. Setting this parameter on at next key-on, the last maintenance hour-counter resets. This operation erases the "SERVICE REQUIRED" warnig if it is present and disable possible reductions.

7.4 Special Adjustment menu

To enter this Zapi hidden menu a special procedure is required. Ask this procedure directly to a Zapi technician.

Following parameter can be configured in this menu:

1) RESET HOURMETER

It can be ON/OFF. If it is ON it is possible to reset the machine hour-counter.

2) RESET ODOMETER

Normally OFF. Set this parameter ON to reset the total distance at next key on.

7.5 Hardware Setting

To enter this Zapi hidden menu a special procedure is required. Ask this procedure directly to a Zapi technician.


Following parameter can be configured in this menu:

1) DISPLAY CONTRAST

It is used to better the display contrast.

7.6 Tester menu

Status of keyboard buttons can be monitored in real time in the TESTER menu.



- 2) **KEY 1**
Status of ▲ keyboard button:
ON = Input active, button pushed
OFF = Input not active, button released
- 3) **KEY 2**
Status of ▼ - TURTLE keyboard button:
ON = Input active, button pushed
OFF = Input not active, button released
- 4) **KEY 3**
Status of ◀ keyboard button:
ON = Input active, button pushed
OFF = Input not active, button released
- 5) **KEY 4**
Status of ▶ keyboard button:
ON = Input active, button pushed
OFF = Input not active, button released
- 6) **KEY 5**
Status of PERFORMANCE - ESC keyboard button:
ON = Input active, button pushed
OFF = Input not active, button released

7) KEY 6

Status of ↵(Enter) keyboard button:

ON = Input active, button pushed

OFF = Input not active, button release

8) ANALOGUE INPUT#1

It display the voltage, in the range [0V, 5V], read on AN1 (CNC#7)

9) ANALOGUE INPUT#2

It display the voltage, in the range [0V, 5V], read on AN2 (CNC#8)

10) ANALOGUE INPUT#3

It display the voltage, in the range [0V, 5V], read on AN3 (CNC#9)

11) ANALOGUE INPUT#4


It display the voltage, in the range [0V, 5V], read on AN4 (CNC#10)

7.7 Description of console using


Access to SET MODEL menu.

The only parameter present in SET MODEL function is CONNECTED TO.


By setting this parameter, operator can connect ZAPI Console to every ZAPI product connected to CAN-BUS line. This functionality allows completely control of every ZAPI product without changing the position of the Console connector.



Flow chart showing how to make changes to Option Menu:



Flow chart showing how to use the TESTER function of the Digital Console:



Remember it is not possible to make any changes using TESTER. All you can do is measure as if you were using a pre-connected multimeter.

7.8 Other functions


SAVE function allows to transfer dashboard parameters to the Pc console memory (using Zapi PcWin console). With this function, a copy of the display set of parameters can be retained in a Pc and downloaded to another dashboard (see RESTORE).

RESTORE function allows to download display parameters from the Pc console memory to the Graphic Smart Display Eeprom. Thus, a copy of the parameters stored in a Pc can be downloaded in a dashboard avoiding the parameter setting operation.

7.9 Description of Alarm menu

The microprocessor in the controller records the last five Alarms that have occurred. Items remembered relative to each Alarm are: the code of the alarm, the number of times the particular Alarm occurred and the Hour Meter count. This function permits deeper diagnosis of problems as the recent history can now be accessed.

Flow Chart showing how to use the ALARMS function via the Digital Console:



8 STRUCTURE OF DISPLAY MENU

Graphic Smart Display present a software structure made by menus and submenus. It is possible to have access to Graphic Smart Display menu structure by the six operator buttons integrated in a membrane keyboard.

At turn on the display asks the starting password to have access to the main page (if "USER PASSWORD" option is ON), otherwise it shows directly the main page (if "USER PASSWORD" option is OFF).

The main page, if there aren't alarms, shows battery charge, truck speed (in Km/h or mph, it depends on "SPEED UNIT" parameter) and key/traction/pump hour meter (see "HOUR COUNTER" option); if alarms are present it will show alarm code and node number in which alarm has occurred.

From the main page it is possible to have access to the ALARM page (if alarms occur) and to MENUS page, that may be USER or SERVICE MENU, it depends on which password is used.

To enter a password is necessary to push the fourth button (M) of membrane keyboard when the main page is showed; this will show a entering password page.

By using user password it's possible to enter USER MENU which will be customized depending on customer requests.

By using service password it's possible to enter SERVICE MENU which presents three items: "password", "zapi console" and "date/hour".


The "password" submenu allows to manage passwords of Graphic Smart Display software structure. It's possible to edit, add and delete passwords.

All passwords are optional (ON/OFF option).

The "zapi console" submenu can be accessible only if CONSOLE ENABLE option is ON. This menu allow user to use dashboard as a real Zapi digital console connected to one module of canbus net.

The "date/hour" submenu allows to modify and watch the display hour and the calendar (used for future customized functions).

It follows flow chart diagram of software structure.



8.1 Performance rolling

From MAIN PAGE using membrane keyboard numbers, it is possible to select the performance mode which must be used in traction and pump controllers. Performance can be chosen with button 4, and it is displayed in the top right side of the unit.

When one performance is selected, the related information will be sent via canbus to traction and pump controllers that will manage this data. The standard functioning reduces truck performance passing from high performance mode (H) to economy performance mode (E).

This is possible only if “PERFORM. ENABLE” option is ON.

The real meaning, in terms of parameters level of these performances, depends on software present on pump and traction controllers.

Button 4 selects in sequence the truck performance (H → N → E).

8.2 Using of Password menu

By entering the service password from MAIN PAGE it's possible to have access to SERVICE MENU. Here with roll buttons (button 1 and 2 of membrane keyboard) it's possible to scroll the submenu items.

With ENTER button (button 6 of membrane keyboard) it is possible to enter PASSWORD submenu where the operator can manage Graphic Smart Display passwords. In particular it could enable/disable password entering, enter, edit and remove passwords.

Inside the PASSWORD menu, use buttons ENTER (6) and OUT (5) to enter or exit submenus and to confirm or cancel operations.

When new password is added, insert:

- the 5 digits password in place of “11111” that appear on the left side of screen;
- the alphanumeric user id in place of “-----“;
- the performance type 0/1/2 (M) related to the password.
- password type (U): S-service / O-user.

To edit or add passwords use these buttons:

Button 1 / Button 2	change the digit marked by cursor
Button 3	shifts cursor on previous digit
Button 4	shifts cursor on following digit
Button 5	cancel all changing
Button 6	saves all changing

When there isn't service password in eeprom, it can be used default password “5555” that is deactivated when at least one service password is saved, and it is reactivated when all service passwords are deleted, then it is not possible save the default password.

8.3 Using dashboard like a console

By entering the service password, from MAIN PAGE it's possible to have access to SERVICE MENU. Here with roll buttons (button 1 and 2 of membrane keyboard) it's possible to scroll the submenu items.

If option CONSOLE ENABLE is ON, with ENTER button, it is possible to enter ZAPI CONSOLE submenu, which allows user to use dashboard as a real Zapi digital console connected to one module of canbus net.

Here with roll buttons (button 1 and 2 of membrane keyboard) and enter button (button 6), it is possible to choose which module of canbus net has to be connected to the display.

When the display has been connected, it works exactly like a Zapi digital console. Buttons of membrane keyboard do the same functions of Zapi console keys.

Button 1	performs function of the ROLL UP console key
Button 2	performs function of the ROLL DOWN console key
Button 3	performs function of the SET DOWN console key
Button 4	performs function of the SET UP console key
Button 5	performs function of the OUT console key
Button 6	performs function of the ENTER console key

8.4 Set Date/Hour menu

By entering the service password from MAIN PAGE it's possible to have access to SERVICE MENU. Here with roll buttons (button 1 and 2 of membrane keyboard) it's possible to scroll the submenu items.

With ENTER button (button 6 of membrane keyboard) is possible to enter DATE/HOUR submenu where the operator can watch and modify the date and the calendar.

Inside the DATE/HOUR menu use buttons ENTER (6) and OUT (5) to enter or exit submenus and to confirm or cancel operations.

To modify hour and date use these buttons:

Button 1 / Button 2	change the digit marked by cursor
Button 3	shifts cursor on previous digit
Button 4	shifts cursor on following digit
Button 5	cancel all changing
Button 6	saves all changing

9 ANALYSIS OF GRAPHIC SMART DISPLAY RELATED ALARMS

9.1 Graphic Smart Display alarms

1) WATCHDOG

Cause:

At start-up the watch dog signal is already active before the software has generated it. At standby or running condition the watch dog signal is not active (in alarm status).

Troubleshooting:

The WD hardware circuit or microcontroller output port are damaged. In both cases no external component are involved. Replace the logic board.

2) COIL SHORTED

Cause:

This alarm occurs when there is a short circuit of the AUXILIARY coil connected to CNB#1 output. After the overload condition has been removed, the alarm exits automatically by releasing and then enabling a travel demand.

Troubleshooting:

The typical root cause for this error code to be displayed is in the harness or in the load coil. So the very first check to carry out concerns connections between dashboard outputs and loads.

In case no failures/problems have been found externally, the problem is in the logic card, which has to be replaced.

3) DRIVER SHORTED

Cause:

The driver of the auxiliary electro valve coil is shorted.

Troubleshooting:

Check if there is a short or a low impedance pull-down between NAUX (CNB#1) and –BATT.

The driver circuit is damaged in the logic board, which has to be replaced.

4) AUX DRIVER OPEN

Cause:

The AUX coil driver is not able to drive the load. The device itself or its driving circuit is damaged.

Troubleshooting:

This type of fault is not related to external components; replace the logic board.

5) HARDWARE FAULT

Cause:

At Key-on the dashboard checks if the AUX driver is turned off by a not active (alarm status) Watch-dog signal. If it is not turned off then the alarm is generated.

Troubleshooting:

The problem is inside the logic, no external component are involved, replace the logic board.

6) CAN BUS KO

Cause:

Graphic Smart Display doesn't receive messages from canbus line or the hour meter synchronization at Key-on fails.

Troubleshooting:

If this fault code is displayed together with other alarm messages, the fault is probably to be looked for in the Graphic Smart Display can interface, since the Display seems to be unable to receive any can message. So it is suggested to check Graphic Smart Display canbus wiring and connection.

Otherwise, the fault is in the can interface of other modules present on canbus network.

9.2 Graphic Smart Display warnings

1) EEPROM KO

Cause:

It's due to an HW or SW defect of the non-volatile embedded memory supporting the dashboard parameters. This alarm does not inhibit the machine operations, but the truck will work with the Graphic Display parameters default values.

Troubleshooting:

Try to execute a CLEAR EEPROM operation (refer to Console manual). Switch the key off and on to check the result. If the alarm occurs permanently, it is necessary to replace the logic. If the alarm disappears, the previously stored parameters will have been replaced by the default parameters.

2) MAINTENANCE NEEDED

Cause:

This is just a warning to call for the time programmed maintenance.

Troubleshooting:

It is just enough to turn the MAINTENANCE DONE option to level ON after the maintenance is executed.

9.3 Alarms visualisation

When an alarm condition occurs, Graphic Smart Display gives the information showing the initial of module in which the alarm occurred, the alarm code and description.

For example, the information:



245 ON PUMP

means that the alarm 245 occurred in the pump controller (M).

Here the table with the alarm codes and the respective meaning is shown.

The meaning of alarms with a code higher than 99 can change depending on the purpose of the application (see following tables).

00	NONE
01	CHOPPER RUNNING
02	NO COMMUNICATION
03	UNKNOWN CHOPPER
04	CONSOLE EEPROM
05	SERIAL ERROR #2
06	SERIAL ERROR #1
07	CHOPPER NOT CONF
08	WATCHDOG
09	FIELD FF FAILURE
10	EEPROM DATA KO
11	EEPROM PAR. KO
12	EEPROM CONF. KO
13	EEPROM KO
14	EEPROM OFFLINE
15	LOGIC FAILURE #5
16	LOGIC FAILURE #4
17	LOGIC FAILURE #3
18	LOGIC FAILURE #2
19	LOGIC FAILURE #1
20	FORW VMN LOW
21	FORW VMN HIGH
22	BACK VMN LOW
23	BACK VMN HIGH
24	LEFT VMN LOW
25	LEFT VMN HIGH
26	RIGHT VMN LOW
27	RIGHT VMN HIGH
28	PUMP VMN LOW
29	PUMP VMN HIGH
30	VMN LOW
31	VMN HIGH
32	VMN NOT OK
33	NO FULL COND.
34	RGT NO FULL COND
35	LFT NO FULL COND
36	PU NO FULL COND
37	CONTACTOR CLOSED
38	CONTACTOR OPEN
39	BRAKE CON CLOSED

40 BRAKE CONT. OPEN
41 DIR CONT. CLOSED
42 DIR CONT. OPEN
43 RIGHT CON CLOSED
44 RIGHT CONT. OPEN
45 LEFT CONT CLOSED
46 LEFT CONT. OPEN
47 MAIN CONT CLOSED
48 MAIN CONT. OPEN
49 I=0 EVER
50 LEFT I=0 EVER
51 RIGHT I=0 EVER
52 PUMP I=0 EVER
53 STBY I HIGH
54 LEFT STBY I HIGH
55 RGT STBY I HIGH
56 PUMP STBY I HIGH
57 HIGH FIELD CUR.
58 NO FIELD CUR.
59 HIGH BRAKING I
60 CAPACITOR CHARGE
61 HIGH TEMPERATURE
62 TH. PROTECTION
63 THERMIC LEVEL #2
64 PUMP TEMPERATURE
65 MOTOR TEMPERAT.
66 BATTERY LOW
67 BATTERY LEVEL #2
68 BATTERY LEVEL #1
69 CURRENT SENS. KO
70 HIGH CURRENT
71 POWER FAILURE #3
72 POWER FAILURE #2
73 POWER FAILURE #1
74 DRIVER SHORTED
75 CONTACTOR DRIVER
76 COIL SHORTED
77 COIL INTERRUPTED
78 VACC NOT OK
79 INCORRECT START
80 FORW + BACK
81 BAD STEER 0-SET

82 ENCODER ERROR
83 BAD ENCODER SIGN
84 STEER SENSOR KO
85 STEER HAZARD
86 PEDAL WIRE KO
87 PEDAL FAILURE
88 TRACTION BRUSHES
89 PUMP BRUSHES
90 DRIVER 1 KO
91 DRIVER 2 KO
92 DRIVER 1 SIC. KO
93 DRIVER 2 SIC. KO
94 INPUT ERROR #6
95 INPUT ERROR #5
96 INVERTION
97 POSITION HANDLE
98 INPUT ERROR #2
99 INPUT ERROR #1

10 RECOMMENDED SPARE PARTS

Part number	Description
C12359	Molex Minifit Connector 6 pins Female
C12358	Molex Minifit Connector 4 pins Female
C12407	Molex Minifit Connector 12 pins Female
C12777	Female Molex Minifit pin harness side

11 PERIODIC MAINTENANCE TO BE REPEATED AT TIMES INDICATED

Checks should be carried out by qualified personnel only and any replacement parts used should be original. Beware of NON ORIGINAL PARTS. The installation of this electronic dashboard should be made according to the diagrams included in this Manual. Any variations or special requirements should be made after consulting a Zapi Agent.

The supplier is not responsible for any problem that arises from wiring methods that differ from information included in this Manual. During periodic checks, if a technician finds any situation that could cause damage or compromise safety, the matter should be brought to the attention of a Zapi Agent immediately. The Agent will then take the decision regarding operational safety of the machine. Remember that Battery Powered Machines feel no pain.

NEVER USE A VEHICLE WITH A FAULTY ELECTRONIC CONTROLLER



IMPORTANT NOTE ABOUT WASTE MANAGEMENT:

This controller has both mechanical parts and high-density electronic parts (printed circuit boards and integrated circuits). If not properly handled during waste processing, this material may become a relevant source of pollution. The disposal and recycling of this controller has to follow the local laws for these types of waste materials.

Zapi commits itself to update its technology in order to reduce the presence of polluting substances in its product.
